

KIOSK

assembly instructions




Hardware checklist:

- 2 x plastic case sections
- 4 x poles (6 if you have a header)
- 1 x plastic lid
- 1 x header section (if you have a header)


1

Put the top case (not the side with the wheels) in the middle of the graphic. Make sure the zip is in the middle on the reverse.




2

Place the vertical support poles in place firmly.




3

Now lift the bottom case (the one with wheels) and place on top of the support poles.




4

Pull the graphic up to the top of the case.



5

Ensure the fabric is straight then place the lid on top and press to secure.




6

Wrap the header section with the graphic and fit the support poles.

7

Place into the holes in the plastic lid.



KIOSK

care instructions

Get the best from your **kiosk**
by following these simple care guidelines:



Ask a friend to help with assembly - four hands are better than two!



Assemble in a dry, clean area and wear the gloves provided when handling the fabric cover.



Position away from windows and back-lit areas to reduce show-through from the reverse.



Use indoors only.



Once assembled, avoid dragging across the floor. Doing so may cause damage.



If the fabric cover becomes dirty, it can be machine washed at 30° with everyday detergents. Cool iron, do not tumble dry.

All fabric components are fire retardant to B1 and M1 standards.