

# FLOOR BOX

## assembly instructions




### Hardware checklist:

- Profile pieces
- Locks
- Screws & nuts
- Allen key
- 2 x Feet
- Extension bar (large floor boxes only)
- Stabiliser bar (large floor boxes only)


**1**

Unpack the profiles carefully and lay them out on the floor. (Ensure they are rested on protective covering so they don't scratch).



**2**

Join any profiles that were split for shipping using the extension bar provided. Slide the bar into one profile and then the other – tighten with the allen key provided.



**3**

Firstly attach the feet. With the feet there are screws with metal nuts. These nuts need sliding into the external profile channel BEFORE the frame is put together.



**4**


The side heavy feet have an upright spur that needs bolting to the edge of the frame. You will need to bolt the base to the bottom profile first and then put the two nuts and bolts into the upright spur loosely without the upright piece of profile.

Slide the upright profile down over the two nuts until it meets the bottom profile – you can then tighten up all the bolts.



**5**


Attach the four pieces of frame together using the corner locks. If fitting stabilisers, leave the corners untightened until they are fitted.



Cont...

6

Fit any internal stabiliser bars horizontally and or vertically. The verticals are complete with locks and run the full height of the frame. The horizontal bars are split into sections and go across the frame intersecting with the verticals. The jaws at each end of the stabiliser bites into the frame channel and vertical stabiliser using the allen key to tighten.



7

Tighten all corners and stabiliser locks and then you can attach your fabric by pressing the silicone edging into the recess of the frame.



## FLOOR BOX

### care instructions

Get the best from your **floor box**  
by following these simple care guidelines:



Ask a friend to help with assembly - four hands are better than two!



Assemble in a dry, clean area and wear the gloves provided when handling the fabric cover.



Use indoors only.



If the fabric becomes dirty, it can be machine washed at 30° with everyday detergents. Cool iron, do not tumble dry.

**All fabric components are fire retardant to B1 and M1 standards.**