

CURVED BACKPACK FLAG

assembly instructions




Hardware checklist:

- 4 x pole sections
- 1 x backpack


1

Take out the poles and the backpack.




2

Connect the poles, then insert into the sleeve which runs the length of the flag. Ensure the pole reaches the very end of the sleeve.





3

Tie the flag to the clasp.



4

Attach the flag to the backpack by clipping the flag pole into the grips on the back of the backpack.



CURVED BACKPACK FLAG

care instructions

Get the best from your **curved backpack flag**
by following these simple care guidelines:



Assemble the flag in a dry, clean area.



Insert the pole with care. Using force may cause the flag to rip.



Position the flag carefully. Air pollution will cause white areas to become grey and UV can, over time, cause fading.



WASH THE FLAG BEFORE USING IT OUTDOORS.

This will reduce the risk of the ink running in the rain.



Machine wash at 30° with everyday detergents. Cool iron.
Do not tumble dry.



Allow the flag to completely dry before putting into storage.



Don't use during adverse weather conditions. Heavy rain combined with high winds can put extra strain on the pole and cause damage.



The life expectancy of the flag is dependant on the climatic conditions and hours of flying - about six months if used regularly.



Do not place too near other flags. Ensure the flag doesn't snag on the pole or other surrounding objects.

All fabric components are fire retardant to B1 and M1 standards.