

# WALL BOX

## assembly instructions



### Hardware checklist:

- 4 x profile pieces
- 8 x locks
- Screws for wall mounting

### You will need:

- Crosstip screwdriver
- Slotted screwdriver


**1**

Place a lock without holes under a lock with holes and small screws. Take a profile piece and put the locks in the according rail in the profile. Put another profile piece on the lock.




**2**

Tighten the two screws of the lock with a slotted screwdriver.




**3**

Repeat step 2 with all locks and profile pieces. Equip the last profile piece with the 4 left locks and put it on the 3 already mounted profiles. Tighten all screws as described in step 2.



**4**

Mark the areas for drilling on the wall with a pencil. Drill the holes into the wall and put the dowels in. Drill corresponding holes in the frame then screw the frame to the wall.



**5**

Insert the fabric by pressing the silicone edging into the recess of the frame.



### Note regarding the wall mounting:

Depending on the wall conditions, different screws and fixings may be necessary. Please check before mounting.

# WALL BOX

## care instructions

Get the best from your **wall box**  
by following these simple care guidelines:

---



Ask a friend to help with assembly - four hands are better than two!



Assemble in a dry, clean area and wear the gloves provided when handling the fabric cover.



Use indoors only.



If the fabric becomes dirty, it can be machine washed at 30° with everyday detergents. Cool iron, do not tumble dry.

**All fabric components are fire retardant to B1 and M1 standards.**